

## INSTALLATION INSTRUCTIONS FOR STANDARD FIXED AWNINGS

**STANDARD AWNINGS TYPES** a) Dome b) Long dome c) Convex d) Small entry canopy  
e) Standard slope

**CRITERIA FOR AN AWNING TO BE STANDARD** a) Height 5' high or smaller b) Projection 5' or smaller c) No wider than 20' d) does not have any post e) consists of only one frame.

Determine mounting height and location on wall where you want the canopy installed.

Using a chalk line, pop a line 1" below where the top of the awning needs to be.

Determine what type of wall you have and use the proper fastener ex;

for wood use lag bolts

for brick use lag shields and lag screws

or you can use plastic anchors

for stucco use toggle bolts.

Using the predetermined fastener, attach the "Z" bracket (supplied) to the wall at 3 to 4 foot intervals. The "Z" bracket needs to be centered along the line that you popped earlier. The reason for this being so that once the frame is sitting in the "Z" bracket it will hide the line that you popped.

After you have the frame sitting in the "Z" brackets and fasteners tightened, you need to secure the frame to the "Z" brackets by using 1/4" x 1" tek screws. There is a hole provided in the "Z" bracket for you to put your tek screw through.